


CHANGING WORKING UNITS



Select **Options > Project Preferences > Working Units Levels**

Make the following changes to work with centimeter as your working units

DISPLAYING REFERENCE LINES




This can be achieved in two ways:

1-Assigning **F4** as the shortcut key


Select **Options > Work Environment > Keyboard Shortcuts**

- Choose “**All Commands in alphabetical order**” in the List,
 - Click the item called “**Clean Wall & Beam Intersections**” ,
 - Type **F4** as the shortcut key in the box,
 - Press **Assign** and **OK** buttons below to complete the process
- You should be able to see the reference lines for walls and beams after pressing the **F4** key



2- Working with **On-Screen View Options** toolbar

Right click anywhere on the main toolbar



Choose the second icon from the left to see reference lines

